

BH-28 ASSEMBLY INSTRUCTIONS

PART LIST	
1-FRAME	
2-MAST	
1-BASE	
2-BOLT	

