

RZ-2 ASSEMBLY INSTRUCTIONS

PART LIST

- 1-BAR 1
- 1-BAR 2
- 2-MAST
- 1-BASE
- 4-NUT
- 4-WHEEL

BOLTS ARE SCREWED
IN PLACE

